

HƯỚNG DẪN CÀI ĐẶT GỬI CẢNH BÁO QUA GMAIL

I.Cấu hình thông số Gmail

Đăng nhập vào thiết bị
Configuration --- > Network --- > Advanced
settings --- > Email

- 1.Đặt tên kiểu cảnh báo
 - 2.Tài khoản Gmail gửi
 - 3.server SMTP “ smtp.gmail.com”
 - 4.Port SMTP “ 587 “
 - 5.User tài khoản gmail gửi
 - 6.Mật khẩu tài khoản gmail gửi
 - 7.Nhập lại mật khẩu tài khoản gửi
 - 8.Địa chỉ Gmail nhận
- Save lại

Live View Playback Picture **Configuration**

Email Platform Access HTTPS Other

Sender báo động 1

Sender's Address sontunghik@gmail.com 2

SMTP Server smtp.gmail.com 3

SMTP Port 587 4

Enable SSL

Attached Image

Interval 2 s

Authentication

User Name sontunghik@gmail.com 5

Password 6

Confirm 7

Receiver			
No.	Receiver	Receiver's Address	Test
1	camera	kythuat@lehoangcctv.com 8	Test
2			Test
3			Test

Save

II. Cài đặt Báo Động

Configuration --- > Event --- > Basic Event --- > Motion

1. Bật “Enable Motion Detection”

2. Chọn “Draw Area” sử dụng

chuột quét vùng.

Save lại

The screenshot displays the 'Configuration' tab of a security camera system. The left sidebar shows a navigation menu with 'Basic Event' selected. The main panel is titled 'Motion' and shows settings for 'Analog Camera 1'. A checkbox for 'Enable Motion Detection' is checked. Below it, there are tabs for 'Area Settings', 'Arming Schedule', and 'Linkage Method'. A video feed of a room is shown with a red grid overlay. Below the video, there are 'Draw Area' and 'Clear All' buttons, a 'Sensitivity' slider set to 3, and a 'Save' button.

Live View Playback Picture **Configuration**

Motion Video Tampering Video Loss Alarm Input Alarm Output Exception

Channel No. Analog Camera 1

1 Enable Motion Detection
 Enable Dynamic Analysis for Motion

Area Settings Arming Schedule Linkage Method

07-16-2018 Mon 09:50:03

Camera 1

2 Draw Area Clear All

Sensitivity 3 3

Save

III. Cài đặt Thời gian Báo động.

Tùy chọn đặt thời gian cảnh báo

Save lại

The screenshot shows a web-based configuration interface for a security camera. The top navigation bar includes 'Live View', 'Playback', 'Picture', and 'Configuration' (which is highlighted in red). Under 'Configuration', there are sub-tabs: 'Motion' (selected), 'Video Tampering', 'Video Loss', 'Alarm Input', 'Alarm Output', and 'Exception'. The 'Motion' tab is active, showing settings for 'Analog Camera1'. The 'Channel No.' is set to 'Analog Camera1'. There are two checkboxes: 'Enable Motion Detection' (checked) and 'Enable Dynamic Analysis for Motion' (unchecked). Below these are three tabs: 'Area Settings', 'Arming Schedule' (selected), and 'Linkage Method'. Under 'Arming Schedule', there are 'Delete' and 'Delete All' buttons. The main area displays a 7-day arming schedule grid. Each day (Mon-Sun) has a horizontal bar representing the arming period from 0 to 24 hours. The grid shows that motion detection is armed for the entire 24 hours of every day.

Day	0	2	4	6	8	10	12	14	16	18	20	22	24
Mon	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed
Tue	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed
Wed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed
Thu	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed
Fri	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed
Sat	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed
Sun	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed	Armed

At the bottom of the configuration page, there is a red 'Save' button.

IV. Kiểu Gửi Cảnh Báo

Chọn “ Send Email ” Gửi cảnh báo qua Email

Audible Warning : âm báo tại đầu ghi

Notify Surveillance Center : gửi cảnh báo qua phần mềm điện thoại

Full screen monitoring : cảnh báo trên màn hình tivi

Upload Pictures to cloud : gửi hình ảnh về server cloud

Save lại

The screenshot shows the Configuration page for Motion detection. The left sidebar lists various settings categories: Local, System, Network, Video/Audio, Image, Event, Basic Event (selected), Smart Event, Storage, Vehicle Detection, and VCA. The main content area is titled 'Motion' and includes a dropdown for 'Channel No.' set to 'Analog Camera 1'. Below this, there are checkboxes for 'Enable Motion Detection' (checked) and 'Enable Dynamic Analysis for Motion' (unchecked). A navigation bar shows 'Area Settings', 'Arming Schedule', and 'Linkage Method' (selected). The 'Linkage Method' section contains a table with three columns: 'Normal Linkage', 'Trigger Alarm Output', and 'Trigger Channel'. The 'Send Email' option under 'Normal Linkage' is highlighted with a red box. A 'Save' button is located at the bottom right.


<input type="checkbox"/> Normal Linkage	<input type="checkbox"/> Trigger Alarm Output	<input type="checkbox"/> Trigger Channel
<input type="checkbox"/> Audible Warning	<input type="checkbox"/> A->1	<input checked="" type="checkbox"/> A1
<input checked="" type="checkbox"/> Send Email	<input type="checkbox"/> A->2	<input type="checkbox"/> A2
<input type="checkbox"/> Notify Surveillance Center	<input type="checkbox"/> A->3	<input type="checkbox"/> A3
<input type="checkbox"/> Full Screen Monitoring	<input type="checkbox"/> A->4	<input type="checkbox"/> A4
<input type="checkbox"/> Upload Pictures to Cloud	<input type="checkbox"/> A->5	<input type="checkbox"/> A5
	<input type="checkbox"/> A->6	<input type="checkbox"/> A6
	<input type="checkbox"/> A->7	<input type="checkbox"/> A7
	<input type="checkbox"/> A->8	<input type="checkbox"/> A8
	<input type="checkbox"/> A->9	
	<input type="checkbox"/> A->10	
	<input type="checkbox"/> A->11	
	<input type="checkbox"/> A->12	

V.Cài đặt Gmail

Kết nối vào Gmail gửi ,vào liên kết

<https://myaccount.google.com/lesssecureapps>

Bật chế độ kém an toàn



The screenshot shows a web browser window with the address bar displaying "Secure | https://myaccount.google.com/lesssecureapps". Below the browser window is the Google logo. The main content area has a blue header with a back arrow and the text "Truy cập kém an toàn từ ứng dụng". Below the header is a paragraph of text: "Một số ứng dụng và thiết bị sử dụng công nghệ đăng nhập kém an toàn hơn, việc này làm cho tài khoản của bạn dễ bị tấn công hơn. Chúng tôi khuyên bạn nên **tắt** quyền truy cập cho các ứng dụng này hoặc **bật** quyền truy cập nếu bạn muốn sử dụng các ứng dụng này bất chấp rủi ro. [Tìm hiểu thêm](#)". Below the text is a toggle switch control. The text "Cho phép ứng dụng kém an toàn: BẬT" is displayed next to the toggle, and the toggle itself is currently turned on (blue). A red hand-drawn rectangle highlights the toggle switch and its label.